

**Step 1:**  
Remove both bolts holding pin in. Keep air in the bag. This is the hardest part of the job.

There are many ways to remove the bolts. The second bolt is the hardest to do. This one can be done after step 2. It will give you room to hold the pin to remove the bolt

**Step 2:**  
Remove the air in the bag. This allows for easier UGT use.


Align UGT to pin. Thread it in so the faces touch. Do not tighten, just touching. Then push the UGT in, by hand, don't use a hammer, until it is even with the housing.

**Step 3:**  
Now you can grease the pin on the side that is sticking out.

**Step 4:**  
Remove the UGT from the first side and install it on the opposite side. Push the UGT, bu ahnd, even with that side face. Now you can grease this side that is sticking out.

**Step 5:**  
Push the pin back to it's original position. Remove UGT and install bolts to factory specs. (aka tight)



UNLESS OTHERWISE SPECIFIED:	NAME	DATE	 <b>Nemesis Industries, Inc</b> 33990 CR-27 T: 303-974-2440 Kiowa, Co 80117 F: 303-953-5212 <a href="http://www.nem-ind.com">www.nem-ind.com</a>	
DIMENSIONS ARE IN INCHES TOLERANCES: ANGULAR: ± .05° TWO PLACE DECIMAL ±.030 THREE PLACE DECIMAL ±.010	DRAWN	MRH 9/13/2024		
<b>DO NOT SCALE DRAWING</b>	APPROVED		Drawing Status	<b>Production</b>
<b>MATERIAL:</b> <b>Custom Plastic</b>	COMMENTS:		Instruction	
<b>THICKNESS:</b>			Part Number <b>Ultimate Greasing Tool</b>	
<b>FINISH:</b>			REV <b>1</b>	
			SHEET 1 OF 1	
<b>PROPRIETARY AND CONFIDENTIAL</b> THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF NEMESIS INDUSTRIES, INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF NEMESIS INDUSTRIES, INC IS PROHIBITED.				